

## Kompatibilitätsliste GPIB-Interfaces für HTBasic

Die folgenden GPIB-Interfaces können unter HTBasic verwendet werden. Stand: Mai 2010

Hersteller	Modellnummer	Bustyp	Treiber für HTBasic Windows 6.x oder älter		Treiber für HTBasic Windows Release 7.x oder höher	
			Win 95/98	NT4/2000/XP Vista / Win 7	Win 95/98	NT4/2000/XP Vista / Win 7
Capital Equipment	CE-01000-00200	ISA	GPIBH	N/A	N/A	N/A
Capital Equipment	CE-01000-00300	ISA	GPIBN	N/A	N/A	N/A
Capital Equipment	PCI-488	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Capital Equipment	488EX	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Capital Equipment	PC488	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Capital Equipment	—	Microchannel	GPIBN	N/A	N/A	N/A
Computer Boards Inc	PCI-GPIB	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	CPCI-GPIB	CPCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	ISA-GPIB	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	ISA-GPIB/LC	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	PCM-GPIB	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	ISA-GPIB-PC2A	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Computer Boards Inc	PC104-GPIB	PC104/ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
HP/Agilent	82335	ISA	GPIBH	N/A	N/A	N/A
HP/Agilent	<a href="#">82350A/B</a>	PCI	HPIBS	HPIBS	HPIBS	HPIBS
HP/Agilent	<a href="#">82357A/B</a>	USB	HPIBS	HPIBS	HPIBS	HPIBS
HP/Agilent	82340A/B	ISA	HPIBS	HPIBS	HPIBS	HPIBS
HP/Agilent	82341A/C	ISA	HPIBS	HPIBS	HPIBS	HPIBS
HP/Agilent	82341D	ISA	HPIBS	N/A	HPIBS	N/A
HP/Agilent	27209	ISA	GPIBH	N/A	N/A	N/A
HP/Agilent	<a href="#">82351A</a>	PCIe	HPIBS	HPIBS	HPIBS	HPIBS
INES	<a href="#">GPIB-PCIE</a>	PCIe	GPIBNI	GPIBNI	GPIBNI	GPIBNI
INES	<a href="#">GPIB-USB</a>	USB	GPIBNI	GPIBNI	GPIBNI	GPIBNI
INES	<a href="#">GPIB-PC</a>	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
INES	<a href="#">GPIB-PCI</a>	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
INES	<a href="#">PCMCIA</a>	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
IOTech	GP488	ISA	GPIBN	N/A	GPIBN	N/A
IOTech	GP488A	ISA	GPIBN	N/A	N/A	N/A
IOTech	Personal 488	ISA	GPIBN	GPIBNI	GPIBN	GPIBNI
IOTech	Personal 488/MM	PC/104	GPIBNI	GPIBNI	GPIBNI	GPIBNI
IOTech	Personal488/AT	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
IOTech	Personal488/CARD	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
IOTech	Personal488/PCI	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
IOTech	Power 488/NB	Parallel	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Keithly Metrabyte	KPC-488.2	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Keithly Metrabyte	KPC-488.2AT	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Keithly Metrabyte	KPCI-488	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Keithly Metrabyte	KPCMCIA	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
Keithly Metrabyte	KPS-488	Microchannel	GPIBNI	N/A	GPIBNI	N/A
Keithly Metrabyte	MBC-488	ISA	GPIBN	N/A	N/A	N/A
National Instruments	AT-GPIB	ISA	GPIBN	N/A	GPIBN	N/A
National Instruments	AT-GPIB/TNT	ISA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	GPIB-1394	Firewire	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	GPIB-ENET	Ethernet	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	GPIB-PCII/IIA	ISA	GPIBNI	N/A	GPIBNI	N/A
National Instruments	GPIB-USB	USB	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	MC-GPIB	Microchannel	GPIBN	N/A	N/A	N/A

Hersteller	Modellnummer	Bustyp	Treiber für HTBasic Windows 6.x oder älter		Treiber für HTBasic Windows Release 7.x oder höher	
			Win 95/98	NT4/2000/XP Vista / Win 7	Win 95/98	NT4/2000/XP Vista / Win 7
National Instruments	PC3	ISA	GPIBN	N/A	N/A	N/A
National Instruments	PCI-GPIB	PCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	PCI-GPIB+	PCI	N/A	GPIBNI	N/A	GPIBNI
National Instruments	PCMCIA-GPIB	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	PCMCIA-GPIB+	PCMCIA	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	PXI-GPIB	cPCI	GPIBNI	GPIBNI	GPIBNI	GPIBNI
National Instruments	PCIe-GPIB	PCIe	GPIBNI	GPIBNI	GPIBNI	GPIBNI
TAMS	<a href="#">L488</a>	Ethernet	HPIBS	HPIBS	HPIBS	HPIBS
TAMS	<a href="#">GPIB-PCIe</a>	PCIe	HPIBS	HPIBS	HPIBS	HPIBS
TAMS	60488 / <a href="#">61488</a>	PCI	N/A	HPIBS	N/A	HPIBS
TAMS	<a href="#">63488</a>	USB	N/A	HPIBS	N/A	HPIBS
TAMS	64487 / <a href="#">64488</a>	PCIe	N/A	HPIBS	N/A	HPIBS
TAMS	<a href="#">65488</a>	PCIe	N/A	HPIBS	N/A	HPIBS
TransEra	<a href="#">Model 900</a>	ISA	GPIB	HPIBS	GPIB	HPIBS / GPIB900
Ziatech	ZT-1444	ISA	GPIB	N/A	N/A	N/A
Ziatech	ZT-1488A	ISA	GPIB	N/A	N/A	N/A
Ziatech	ZT 8847	STD	GPIB	N/A	GPIB	N/A
Ziatech	ZT 8848	STD	GPIB	N/A	GPIB	N/A

**Bitte beachten Sie:**

Windows Vista und Windows 7 erfordern den Einsatz von HTBasic for Windows Release 10 oder höher.

Um ein aufgeführtes Interface unter Windows Vista und Windows 7 nutzen zu können, muß der Hardwaretreiber des Herstellers ebenfalls Windows Vista / Windows 7 unterstützen, da HTBasic auf den herstellerspezifischen Hardwaretreiber zugreift.

**Erstellt von:**

Tech Soft GmbH  
Karmeliterweg 114  
13465 Berlin

<http://www.HTBasic.de>